


A How MyWirelessTV Works

MyWirelessTV allows you to place an HDTV anywhere in your home because it transmits your video and audio wirelessly.



Make sure you identify which 'source device' that you want to connect to the Transmitter. Video from that 'source device' will be transmitted to your receiver box(s).

INSTALLATION for the MyWirelessTV is **EASY**. Both units come pre-paired to work with each other. All you need to do is connect the cables according to the diagram or, if you want, follow the detailed step-by-step instructions.

Note: Only use power adapter, Leader Electronics Inc., Model MU12-G050200-A1

B Connect the Cables

Step 1a Get one **power supply** from MyWirelessTV Kit. Plug the smaller end of the **power supply** into the **5VDC port** on the back of the **Transmitter**.



Step 1b Plug the larger end of the **power supply** into a **power outlet**.



Step 1c Make sure the **Power Light** on the Transmitter is **SOLID Green**.



Note: The Sync light may blink

If you are using the Transmitter and Receiver in the same room, please skip to step 3a

Step 2a Unplug the HDMI cable from the back of the **Source Device** (ie: a cable/ satellite set-top box, Blu-ray player, etc.). Plug this **free end** of the HDMI cable into the **HDMI Out to TV port** on the back of the **Transmitter**. Please note this step is optional. You are not required to use the HDMI out to TV port on the Transmitter.



Step 3a Get an **HDMI cable** from MyWirelessTV Kit. Plug one end of this **HDMI cable** into the **HDMI Input port** on the back of the **Transmitter**.



Step 3b Plug the other end into the **HDMI port** on the **Source Device** from Step 2.



Step 4a Get the second **power supply** from MyWirelessTV Kit. Go to the HDTV that you want to connect.



Step 4b Plug the smaller end of the **power supply** into the **5VDC port** on the back of the **Receiver**.



Step 4c Plug the larger end of the **power supply** into a **power outlet**.



Step 4d Make sure the **Power Light** on the **Receiver** is **SOLID Green**.



Step 4e Wait 30-45 seconds. All 3 **lights** on the **Receiver** should be **GREEN**.



Note: If the Sync Light is SOLID Orange, wait another 10-15 seconds. It should turn GREEN. If the Sync Light stays Orange or Red, you will need to manually pair the units. Please refer to the user manual for more information.

Step 5a Get the second **HDMI cable** from MyWirelessTV Kit.



Step 5b Plug one end of this **HDMI cable** into an **HDMI port** on the **HDTV**.



Step 5c Plug the other end of the **HDMI cable** into the **HDMI Out to TV port** on the back of the **Receiver**. The HDTV should now be connected to the Receiver.



Step 5d Turn on the HDTV near the Receiver. Make sure you have selected the correct source input. You should be able to see video from the source device.

Flip this Quick Start Guide over to continue **NEXT**

C Setting Up IR Control (Optional)

The IR Blaster and IR Receiver work together to let you control the source device (the device to which you connected the Transmitter: DVR, Blu-ray Player, etc.) from the Receiver location, whether it's in the next room, or on the other side of the house. For example, if your source device is in the living room, and you've set up your My Wireless TV in your bedroom, the IR Blaster/Receiver allows you to control the source device from your bedroom.

If you are using the MyWirelessTV Kit in the same room, the IR Blaster is not needed.

Use an **IR Extender** cable if the receiver is hidden or you want it to be hidden. Use of this cable is optional.

Step 6a Get the **IR Extender** cable (with the **green** connector) from the MyWirelessTV kit.



Step 6b Plug the IR Extender cable's **green connector** into the **Green port** on the back of the **Receiver**.



Step 6c Remove the protective covering of the doublestick tape and attach the **flat end** of the IR Extender cable to the front corner of the **HDTV bezel or frame**.



Step 7a Get the **IR Blaster cable** from MyWirelessTV kit. The IR Blaster cable has a **black** connector.



Step 7b Plug the IR Blaster cable's **black connector** into the **Transmit port** on the back of the **Transmitter**.



Step 7c Place the **flat end** of the IR Blaster cable in front (not directly over) of the **remote sensor** of the **source device**.



Your HDTVs and cable/satellite box should be connected as shown in the previous diagram. You can now start enjoying HDTV anywhere you want it!

CAUTION
RISK OF EXPLOSION IF REMOTE CONTROL BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

D Troubleshooting

FREQUENTLY ASKED QUESTIONS

1 Q I'm not seeing anything on the TV screen near the Transmitter.

A Check the cable connection from the source (i.e. Cable/Satellite Set Top Box) to the Transmitter and from Transmitter out to the HDTV.

2 Q My cables are connected properly, but I'm still not seeing video on my TV screen.

A Make sure the source device is powered on and the correct source input is selected on your HDTV.

3 Q I'm not seeing anything on the TV screen next to the Receiver.

A Check the cable connection from the MyWirelessTV Receiver out to the HDTV. Also, make sure the correct source input is selected on the HDTV.

4 Q I can't control my source device (Set Top Box, Blu-Ray Player, etc.) from my 2nd HDTV.

A Make sure the IR blaster sensor is pointed directly to the source device's IR (infrared) window. Also make sure the Receiver or the IR Extender cable is in line-of-sight of the remote control.

5 Q I can't change my channel or volume with the remote control included with the MyWirelessTV Kit.

A The MyWirelessTV remote control provided is intended for switching multiple input, pairing configuration, and software update. It is not a universal remote control.

6 Q I do not see any video when I connect to my PC/Laptop with HDMI to the MyWirelessTV.

A Make sure the HDMI output display is selected from your PC/Laptop. Refer to your PC/Laptop's user manual.

7 Q The video quality is poor.

A You may need to adjust the orientation of the Transmitter and Receiver. Use the Wireless Power Indicator to improve the wireless signal between the two devices. You may want to try orienting the Transmitter and Receiver fronts to be pointing more directly at each other. To learn more, see the MyWirelessTV user manual.

For Technical Support call
1-888-436-0657

How to Videos, User Manuals, Wall Mount Templates, Software Updates and other information are available Online at
<https://www.actiontec.com/products/product.php?pid=219>



Multi-Room Wireless HD Video Kit

My Wireless TV

Model # MWTV200KIT (MWTV200T/MWTV200R)

Quick Start Guide

This Quick Start Guide will walk you through the easy steps to set up MyWirelessTV. During this process, we'll show you how to connect a second HDTV to an existing HDTV cable/satellite box, DVR, or other HDMI device (Blu-ray player or gaming console, for example).

- A** How MyWirelessTV Works
- B** Connect the Cables
- C** Setting Up IR Control
- D** Troubleshooting

You will need the following items from your MyWirelessTV kit:

- Wireless HD Transmitter
- Wireless HD Receiver
- Two (2) Power Supplies
- Two (2) HDMI Cables
- IR Blaster Cable
- IR Extender Cable

© 2011 Actiontec Electronics, Inc. Actiontec, Actiontec Installation Buddy, Creative Solutions for the Digital Life, and the Actiontec logo are trademarks or registered trademarks of Actiontec Electronics, Inc. in the U.S. or other countries. All other names are properties of their respective owners. Product photo may differ from actual product, however functionality remains as stated above. Specifications are subject to change without notice.

